

## OPTIFOG™ CARE

A lens with Optifog technology can hold the Optifog Activator for up to one week, far surpassing the anti-fog durability of any other lens or spray.



Start with clean lenses and shake the Optifog Activator



Apply one drop on each side of the lenses



Gently wipe the lenses using the provided microfiber cloth



Under normal use, reapply once a week. The bottle should last 6 months

Repurchase Optifog Activator at your eye care provider or order at [optifogusa.com/activator](http://optifogusa.com/activator)



Ask us today about our **NEW**  
fog free vision solution.

[OptifogUSA.com](http://OptifogUSA.com)



**OPTiFOG™**

STOP THE FOG WITH  
**OPTiFOG™**

# FOG IS EVERYWHERE:

In daily activities at home, work and play, fogged lenses can be a real bother or hazard.

## CHANGING ENVIRONMENT

Moving from cold to warm areas



## OUTDOOR ACTIVITIES

Playing sports like tennis, running or cycling



## INDOOR ACTIVITIES

Boiling water, drinking hot beverages or opening the dishwasher




## AT WORK

Work environment where precision and safety are a priority



# FOG FREE VISION:

Escape annoying, dangerous fog with the new technology of Optifog. The combination of the lens with Optifog technology and the Optifog Activator provides long lasting, fog free vision.



LENS WITH OPTIFOG TECHNOLOGY



OPTIFOG ACTIVATOR



**LONG  
LASTING,  
FOG FREE  
VISION**

**OPTiFOG™**